

LINDY®

CONNECTION PERFECTION

KVM Extender DVI & USB 2.0

English Manual

This manual covers the DVI & USB 2.0 KVM Extender family:

Transmitters (TX)

39200: DVI & USB 2.0 Transmitter with HDMI connectors

39210: DVI & USB 2.0 Transmitter with DVI connectors

39240: DVI & USB 2.0 Transmitter with DVI connectors and
Fiber Optic connection

Receivers (RX)

39201: RX with HDMI connectors, USB 2.0 without
Storage

39202: RX with HDMI connectors, USB 2.0 with Storage

39211: RX with DVI connectors, USB 2.0 without Storage

39212: RX with DVI connectors, USB 2.0 with Storage

39213: RX with DVI connectors, USB 2.0 without Storage,
with Audio Option

39214: RX with DVI connectors, USB 2.0 with Storage and
Audio Option

39241: RX with DVI connectors, USB 2.0 without Storage,
with Fiber Optic connection

As well as all further models under special make numbers with activated options and combination of options

Introduction and Features

This KVM extender allows you to connect consoles to computers via a distance of up to 130m for direct Cat.6 cable connection, or up to 200m via a gigabit network switch, or up to 500m/20km via fibre optic modules Multi/Single Mode. The KVM signals are transmitted either via Cat.6 or via Duplex LC cables. The Extender uses digital transmission ensuring there is no signal degradation as is typically experienced when using KVM extenders for analogue VGA signals.

This extender family supports digital DVI-D Single Link signals up to 1920x1200. For reasons of space, the Extenders 39200 - 39202 use HDMI receptacles, but HDMI features such as audio, HDCP, YUV/YCbCr, deep colour are NOT supported.

This extender family supports almost all USB 1.1/2.0 devices, but USB flash drives and USB hard drive enclosures are supported only by extender versions with Mass Storage support - this option can be upgraded if required via paid unlock code (SN based) - please contact LINDY support. LINDY support also can provide additional information for various mounting kits.

For the whole extender product family the following additional features can be upgraded via SN-related paid unlock code (combinations of unlocks are also possible):

Mass Storage option, analogue audio option*, VGA option*, RS232 option*, matrix switching option.

* marked options are only available for models with DVI ports!

The matrix switching option introduced in 2015 requires the connection of all extender boxes via one Gigabit switch. Each KVM connection requires 1Gbit/s bandwidth! Therefore switches cannot be cascaded, or they require at least a 10Gbit/s. connection. Therefore as also for security reasons the KVM network must be always separated.

Options must be purchased exclusively for the receiver and will automatically become available on the connected transmitter. The VGA option allows the feeding of VGA sources, VGA signals are digitized and transmitted and output as digital DVI-D signals from the receiver. Back conversion back to VGA requires an additional external converter. In a Matrix Switching network options must be purchased for all receiver units.

In the versions with fibre optic connection the SFP module can be replaced against a single mode version for distances up to 20 km.

Packaging Content TX and RX

- 1x Transmitter (TX)
- 1x power supply incl. 4 adapters
- 1x DVI-HDMI respectively DVI-DVI cable, 2m
- 1x USB cable A/B, 2m
- 4x housing feet
- 2x self-adhesive hook and loop pad
- Manuals (DE, EN, FR, IT)

- 1x Receiver (RX)
- 1x power supply incl. 4 adapters
- 1x DVI-HDMI respectively DVI-DVI cable, 2m
- 4x housing feet
- 2x self-adhesive hook and loop pad
- Manuals (DE, EN, FR, IT)

Installation, Operation

The KVM extender basically consists of a transmitter (TX) and receiver (RX). The TX (see product label or imprint **local** / **pc** on the front panel) connects the computer or the DVI signal source to the KVM extender by enclosed monitor and USB cables. The RX provides a bypass port for a local monitor.

The RX (see product label or imprint **remote** / **mon** on the front panel) connects to the user console, the monitor by the enclosed monitor cable. The RX supports direct connection of 4 USB devices and/or USB hubs as well.

If you want to secure the transmitter and receiver to prevent slipping, attach the self-adhesive hook and loop pads (enclosed) to the underside of the device. Accessories like mounting brackets, DIN rail, as well as a 19 inch rack mount shelves are available on option – please contact LINDY support.

The transmitter and receiver are connected with shielded Cat.5e/6/7 or LC-duplex cables. To achieve maximum distances using cat. 6/7 direct connection please use high-quality solid core CAT 6 or higher cable, E.g. LINDY no. 12047 / 12048.

Connect the power supply and switch on all devices. After connecting or turning on, the transmitter and receiver automatically perform a cable or connection test and calibration for approximately 5-10 seconds. During this process the status LED on the front panel will flash different colours; the meaning also is printed on the front panel.

staus	link	video
RED	X	X
ORANGE	✓	X
GREEN	✓	✓

When using HDMI monitors and HDMI/DP graphic cards colour distortions may occur because the EDID signal of the monitor is forwarded by the Extender. In this case, set the graphics output to RGB signal, max. 32 bit or 8 bit colour depth, without HDCP. Or use a DVI output on the graphic card. Alternatively the DDC settings of the extender can be set to a fixed preset value – see further below.

USB connections are hot pluggable. It is normal that after plugging a USB device this must be first recognized and re-loaded. Via the Extender, a slightly larger amount of time is required for this than for direct computer connections.

On Screen Menu

In the on screen menu device settings can be configured and displayed. It also is used to update the firmware as well as for activation of fee-based upgrade options like mass storage, audio, VGA, RS232, and the switching option.

By security reason (configurable setting) the on screen menu can be accessed only in the first few minutes after switching on the Extender. To access the OSD the "Scroll Lock" key on the keyboard must be pressed 5 times in quick succession. If the OSD does not appear because the lock function is already active, turn the Extender off/on and try again.

Menu item "U" is used to perform a firmware update. The firmware is available on request at the LINDY tech support.

Menu item "M" indicates the installed options. The USB mass storage support may temporarily be switched off if installed. To change the options, you must purchase a fee-based activation code dependent on the device ID for each RX. Note the device ID displayed in the menu and contact LINDY support. This activation code can be entered after entering the command "M" in this menu.

Menu item "O" adjusts the treatment of the DDC/EDID data. 0 or 1 defines to use the data of either the remote or local monitor; the other settings define to use preset EDID/DDC and resolutions.

Menu item "W" - network settings: refer to the switching section.

Sub-menu item "K" - keyboard language. Currently, the language layout can be selected between German, English, French. Swiss and Italian may be added in the future.

Menu

```
T = Status Overview
U = Update Flash FW
M = Option Overview
O = DDC Option (remote monitor)
W = Network Settings
G = Extender Settings
K = Keyboard Locale (EN)
Q = Exit
```

```
Remote (Con) FW Ver = 4177
Local (PC) FW Ver = 4177
```

Options Overview

```
[USB Memory] - Enabled
                (1 - enable, 0 - disable)
[RS232]         [VGA]
[Sound]         [Switching]
```

```
Device ID: 123456f7
Send ID to distributor to unlock
options.
```

```
Press M to enter code.
```

DDC Options

```
+-----+
0 = remote monitor
1 = local monitor
2 = last DDC fixed
4 = FIX 1024x768
5 = FIX 1280x1024
6 = FIX 1680x1050
7 = FIX 1920x1080
8 = FIX 1920x1200
```

Menu item "G" - Extender settings: this menu leads to another further submenu of other settings:

Sub-menu item "V" - VGA digitization settings. When the VGA option is enabled a VGA input signal can be digitized automatically and manually. The M command toggles between Auto-detect / DVI / VGA. The K command allows the manual VGA fine tuning using the keys F1 through F8. During manual adjustment the space bar changes the rate of change cyclically.

I button restores the default settings.

Sub-menu item "A" - amplification of the audio input on the remote unit. The default is 5, 0 turns off the input signal, 9 is the maximum gain.

Sub-menu item "R" - RS232 settings. The D9 interface assignment is as follows: pin 3 transmit data, 2 receive data, 4 DTR, 8 CTS. The universal rate of 9600 transfers all RS232 transparent configurations. The following settings are available: baud rate: 4800, 9600, 19200, 38400, 57600, 115200, 230400; Parity: No, odd, even, mark, space; Stop bits: 1, 2.

Sub-menu item "S" - show last image. When this function is enabled the Extender shows the last transmitted frame before a connection was aborted instead of a black screen. The screen then is marked with red flashing frame.

Submenu item "I" - Monitor sync. Synchronizes the image refresh rate of monitor with graphics card, what can be useful for multimedia content. Because not all monitors support this function the default setting is off. A flickering monitor is an indication that he does not support this function.

Sub-menu item "L" - lock menu. Here, it can be set whether or not the access to the OSD 5 minutes after switching on is blocked.

Sub-menu item "P" - Power save menu. Here, the behaviour of the monitor power save mode is set. If the Extender receives no video signal it can also turn off its output signal so that the connected monitor also switches to power save.

Sub-menu item "N" - noise filter. Here, an image enhancement for content with very high dynamics (video with very rapid image changes or noise) can be set. If for such signals the frame rate drops below a critical limit a noise filter can improve the image transfer. It should only be enabled together with the monitor sync option above and not without real need.

Sub-menu 'Q' - exits the sub-menu.

```
Extender Settings
+-----+
V = VGA parameters
A = Audio Input Gain (5)
R = RS232 Baudrate (up to 9600)
S = Show Last Image (disabled)
I = Monitor Sync (disabled)
L = Lock Menu (disabled)
P = Power Save (enabled)
N = Noise Filter (enabled)

Q = Return to Main Menu
```

```
Shift      up F1  F4 down  0
Shift      <- F2  F3 ->   0
Zoom       out F5  F6 in   2200
Pixelfine  - F7  F8 +     0

Space = 1/10 steps
M = Video Mode Auto
K = Automatic seek
I = Init VGA Table
S = Save - exit
Q = Quit - no save
```

```
Lock Menu 5 Min after
Power-On is disabled
```

```
Enter  1 for enable or
       0 for disable:
```

Network and Matrix Switching Menu and Options

The matrix KVM Switching option has been added to this KVM extender series in 2015. It is available as a fee-based option and is activated via an unlock code. Older extender boxes require an additional firmware update to enable their switching option. In a Matrix switching network the options must be purchased and installed on all RX units. The RS232 option requires special hardware in order to function.

Main menu item "W" - network settings provides access to the advanced menus to configure the network and switching options. Please note that this menu item is only active when the Switching Option has been unlocked on the RX. In order to prevent unauthorized access to the Network Settings this menu is protected by password. Access is only allowed for users with administrator rights. The factory settings provide an administrator user with User: admin and Password: admin. Please change at least the password and record the new settings in a secure place.

Sub-menu item "R" – sets all settings to factory default, also all user, console and computer settings will be deleted.

Sub-menu item "P" – turn on the password system for users and groups, see further below. This password system is different and independent from the password access to the network settings.

Sub-menu item "T" – Timeout settings, the following options are available:

I – Immediately – enables password security to every switch, activated without reboot.

N – Never – password is required only after logout.

T – Time in minutes – time period with inactivity for automatic logout

Sub-menu item "C" – Auto-Connect. Available only if the password system is disabled: switches to the next free port/computer if the KVM connection is separated by another user.

Sub-menu item "V" – Private Connection. To prevent the takeover of the connection by other users. To enable this feature the SHIFT key (uppercase) must be pressed when establishing the connection (via OSD or hotkey).

Sub-menu item "B" – User-PC binding. Upon activation, the switch network introduces restrictions for standard users. Each console shows the password login screen. The admin has to assign a computer to every user. After login users are automatically connected to their assigned computer, they cannot switch to other computers. A user may log out with CTRL-ALT-F11. Only master and admin accounts can also access other computers.

Sub-menu item "D" – Disconnect on Power Down / Switch off. Enabled: If a computer is switched off, also the KVM connection the TX unit is disconnected.

Sub-menu item "M" – Master View – Network configuration. Admin console to manage the users, consoles and computers. The following menu items are accessible only for the master:

Master View Menu "C" – Connections Overview. Shows the existing connections and the free consoles and computers. Connections can be interrupted or assigned as well.

```
NETWORK SETTINGS
+-----+
R = Reset to Factory Default
P = Passwords Disabled
T = Set Timeout (Immediately)
C = Auto Connect Enabled
V = Private Connections Disabled
B = User-PC Binding Disabled
D = Dcon on PC Power Down Enabled

M = Master View (Network Configuration)
Q = Save and Exit
```

```
MASTER VIEW menu
+-----+
C = Connections Overview
U = User List
W = Console Extender List
S = PC Extender List
H = Multi-Head Configuration

Q = Exit
```

```
MASTER VIEW connections overview
+-----+
> SERVER 1      <--> CONSOLE 1
  SERVER 2      <--> CONSOLE 2
  SERVER 3      <--> CONSOLE 3
                   CONSOLE 4

I = Show Details
Q = Exit
```

```
MASTER VIEW connections detail
+-----+
> Computer:      SERVER 1
  Workstation:    CONSOLE 1
  User:           <None>

D = Force Disconnect
E = Select PC for workstation
Q = Exit
```

Master View Menu "U" – User List. Administration of users and user groups.

```
MASTER VIEW user list
```

--USER-----+	GROUPS--++	RIGHTS--+
> admin	1,2,3,4,5..	admin
master	1,2	master
user	1	user

A = Add R = Remove
I = Info Q = Exit

```

MASTER VIEW user list
--USER-----+--BOUND PC-----+
> admin      | <None>
  User1      | SERVER 1
  User2      | SERVER 2
              |
              |
              |
A = Add      R = Remove
I = Info     Q = Exit

```

User: Define a login name and password up to 16 characters.

Full Name: assigns the full name of the user. This full name is shown to other users, when this user interrupts their connection.

Password: required for login, max. 16 characters

Rights – there are 3 kinds of rights: User, Master and Admin. By pressing the + key the rights are toggled.

Admin can interrupt the connection of master and user. If an admin interrupts the connection of another Admin, the latter can retrieve the connection. Private connections cannot be interrupted.

Master can interrupt the connections of users. If a master breaks the connection of another master, the latter can retrieve the connection. Admin, master and private connections cannot be interrupted.

User: If a user disconnects another user's connection, the latter can retrieve the connection. Admin and private connections cannot be interrupted.

Groups: Each user can be assigned to one of 8 user groups. Each computer is also assigned to a user group. By default, all computers are in the same group. The user assignment to a group is done by entering the digit 1 to 8.

Bound PC: If the User-PC binding is active (see above: sub-menu item "B") each user must have a PC assigned. In the user details menu the computer selection menu can be displayed by pressing the RETURN key.

```

MASTER VIEW user detail
+-----+
> USER:      admin
  FULL NAME:  Administrator
  PASSWORD:   admin
  RIGHTS:     *** (admin)
  GROUPS:     1,2,3,4,5,6,7,8
  Bound PC:   SERVER 1

```

A = Add R = Remove
 I = Info Q = Exit

Master View Menu "W" – Console Extender List.

Shows the console list with all connections.

..this“ shows the connection of the own console.

„in use“ shows an active connection of another console.

„free“ shows that the console is not connected to a computer/TX.

A name can be assigned to each console.

```
MASTER VIEW console extender list
--NAME-----+--STATUS--+
> Workstation1      | this
  Workstation2      | in use
  Workstation3      | free
                   |
                   |
                   |
R = Remove (Disconnected Only)
I = Info           Q = Exit
```

Master View Menu "S" – Computer Extender List.

Shows all computers in the system and their group assignment and status. Also here a name can be given via the Info menu, the group assignment is done by entering the numbers 1 to 8.

```
MASTER VIEW PC extender list
--NAME-----+--GROUP--+--STATUS--+
> SERVER1      |      1  | conn'd

|              |        |
|              |        |
|              |        |

R = Remove (Disconnected Only)
I = Info           Q = Exit
```

Master View Menu "H" – Multi-Head Configuration

If you use multiple monitors per computer each graphic channel and each monitor requires individual Extender boxes that have to be grouped in the Extender OSD menu via multi head configuration. To simplify the mapping individual names should be assigned to the console and computer boxes. To assist in the name assignment, the LED on each Extender box is flashing red/green if it is just configured. It may be helpful to connect all Extender boxes to a switch locally in one place to configure the network. In this case you only need one console to configure all Extender boxes.

```
MASTER VIEW multi-head configuration
--MULTI-HEAD SET-----+--TYPE--+--SIZE--+
> MULTIHEAD_SERVER      |  PC   |  3
  DUALHEAD_CONSOLE      | Console |  2
  DUAHLHEAD_SERVER      |  PC   |  2
  MULTIHEAD_CONSOLE     | Console |  3

|              |
|              |

A = Add           R = Remove
I = Info          Q = Exit
```

Open the multi-head configuration menu and create a new MULTI-HEAD SET for each computer and for each console by pressing the **A** button. In the submenu multi-head detail, you can configure the individual multi-head configuration settings by selecting the corresponding boxes. The type is detected automatically after establishing the first connection.

```
MASTER VIEW multi-head detail
+-----+
> Name:   mhs1
  Type:   Undefined
  Heads:  0
--Module List-----
SERVER 1/1      | conn'd
SERVER 1/2      | in use
SERVER 1/3      | in use

A = Add Module    E = Edit
Q = Exit and Save
```

To leave this menu and save settings press the **Q**.

The details menu can always be brought up by pressing **I** in the main Multi-Head menu. By pressing **R** you can remove an extender from the Multi-Head set.

Multi-Head Set connections are always switched together in combination.

Matrix Switching via OSD and Hotkey

The KVM Switching OSD is invoked by the hotkey **CTRL+ALT+F12**.

It lists all computers and their status in the switching network.

In **BLUE** the recently connected computer is listed.

In **White** the other computers with connection to a console are listed.

In **Green** powered computers without connection to a console are listed.


In **Red** computers / RX boxes are listed that once have been connected but are not available recently. If required, these entries can be deleted by pressing the DELETE key.

Select a computer (>) by cursor keys up / down, the **RETURN** key switches to the selected computer. The order (line number) of the computers in the menu can be changed by typing the desired number in a row and the list will be reorganized.

The hotkey combination **CTRL+ALT+F4** switches to computer no. 4 in the list.

If the password system is active the user will be displayed in the OSD at the bottom.

The key **X** logs out, the key **D** interrupts the recent connection to the selected computer.



Trouble shooting

If you cannot solve problems with this Extender please contact our support. You can reach us worldwide at the numbers listed on our website. Or send us an email to support@lindy.com.

Legal Information

Hersteller / Manufacturer (EU):

LINDY-Elektronik GmbH
Markircher Str. 20
68229 Mannheim
GERMANY
Email: info@lindy.com , T: 0049 (0)621 470050

LINDY Electronics Ltd.
Sadler Forster Way
Teesside Industrial Estate, Thornaby
Stockton-on-Tees, TS17 9JY
United Kingdom
postmaster@lindy.co.uk , T: +44 (0) 1642 754000

WEEE (Waste of Electrical and Electronic Equipment), Recycling of electronic products

In 2006 the European Union introduced regulations (WEEE) for the collection and recycling of all waste electrical and electronic equipment. It is no longer allowable to simply throw away electrical and electronic equipment. Instead, these products must enter the recycling process. Each individual EU member state has implemented the WEEE regulations into national law in slightly different ways. Please follow your national law when you want to dispose of any electrical or electronic products. More details can be obtained from your national WEEE recycling

CE Declaration of Conformity

This equipment complies with the requirements relating to Electromagnetic Compatibility Standards EN55022/EN55024 and the further standards cited therein. It must be used with shielded cables only.
It has been manufactured under the scope of RoHS compliance.