

CONTENT

INTRODUCTION	1
I. Install the driver of USB-IrDA Adapter	2
➤ Under Windows 98SE	2
➤ Under Windows ME.....	7
➤ Under Windows 2000	10
➤ Under Windows XP	12
II. Make sure the USB-IrDA Adapter installed successfully	16
➤ Under Windows 98SE/ME.....	16
➤ Under Windows 2000/XP	17
III. Uninstall the driver of USB-IrDA Adapter	18
➤ Under Windows ME.....	18
➤ Under Windows 2000/XP	20

INTRODUCTION

Thank you for choosing the **USB-IrDA Adapter** solution, it is compliant with the USB 1.1 specification. The **USB-IrDA Adapter** supports FIR (4Mbps) and SIR (115200bps) baud rate to the infrared devices, ex: mobile phone, PDA, notebook...etc.

SYSTEM REQUIREMENTS

- USB host controller.
- Windows 98/Me/2000/XP operating system.

PACKAGE CONTENTS

- USB-IrDA Adapter x 1
- USB A to B type cable x 1
- User Manual x 1
- CD x 1

NOTE

- Please install the driver before plugging the **USB-IrDA Adapter** into USB port of your PC or Notebook.

I. Install the driver of USB-IRDA Adapter


➤ Under Windows 98SE

Step1.

- Plug the **USB-IRDA Adapter** into the USB port of your PC or Notebook.


Step2.

- Click "**Next**" to continue the driver installation.



Step3.

- Select the “**Search for the best driver for your device.**” item.
- Click “**Next**” to continue.



Step4.

- Select “**Specify a location**” item and click “**Browse**” item to specify the “Dry98” folder of driver CD.
- Click “**Next**” to continue.




Step5.

- Click “**Next**” to continue.



Step6.

- Please put your Windows 98se source CD to the CD-ROM.
- Click “**OK**” to continue.




Step7.

- Click “**Finish**” to complete the driver installation.



Step8.

- Click “**Yes**” to reboot the OS and take effect the new hardware.




Step9.

- Move the cursor to the IRDA icon of right and underside of desktop.
- Click the mouse right button to select “Open” item.



Step10.

- Select “Options” item.
- Click “**Enable infrared communication**” check option to enable.
- Click “OK” to complete the setting and close the Infrared Monitor.




➤ Under Windows Me

Step1.

- Double click the “**SETUP.EXE**” program of the driver CD to install the **USB-IRDA Adapter** driver.


Step2.

- Click “**Next**” to continue.




Step3.

- Click “**Next**” to continue.




Step4.

- Plug the **USB-IRDA Adapter** into the USB port of your PC or Notebook.
- Click “**Finish**” to complete the driver installation.



Step5.

- Select “**Yes, I want to restart my computer now**” item.
- Click “**Finish**” to reboot OS.




➤ **Under Windows 2000**

Step1.

- Double click the “**SETUP.EXE**” program of the driver CD to install the **USB-IRDA Adapter** driver.


Step2.

- Click “**Next**” to continue.




Step3.

- Click “**Next**” to continue.



Step4.

- Click “**Finish**” and plug the **USB-IrDA Adapter** into the USB port of your PC or Notebook.




➤ **Under Windows XP**

Step1.

- Double click the “**SETUP.EXE**” program of the driver CD to install the **USB-IRDA Adapter** driver.


Step2.

- Click “**Next**” to continue.



Step3.

- Click “**Next**” to continue.




Step4.

- Select “**Continue Anyway**” button to continue.



Step5.

- Click **“Finish”** and plug the **USB-IrDA Adapter** into the USB port of your PC or Notebook.



Step6.

- Select **“Install the software automatically”** item and click **“Next”** to continue.



Step7.

- Click “**Continue Anyway**” button to continue.



Step8.



- Click “**Finish**” to complete the hardware installation.



II. Make sure the USB-IrDA Adapter installed successfully


➤ Under Windows 98SE/ME

- Please move the cursor to “My computer” → “Control Panel” → “System Properties” → “Device Manager”.
- It will show the “Infrared Communication Device”; “USB-IrDA Adapter”; “Virtual Infrared COM port” and “Virtual Infrared LPT port”.



➤ **Under Windows 2000/XP**

- Please move the cursor to **“My computer”** → **“Control Panel”** → **“System Properties”** → **“Hardware”** → **“Device Manager”**.
- Double click **“Infrared devices”** and it will show the **“USB-IrDA Adapter”**.




III. Uninstall the driver of USB-IrDA Adapter

➤ Under Windows ME


Step1.

- Move the cursor to “**My computer**” → “**Control Panel**” → “**Add/Remove Programs**” and double click.
- Select the “**USB-IrDA Adapter**” item and click “**Add/Remove**” button to uninstall the driver.




Step2.

- Click “**Yes**” to uninstall the **USB-IrDA Adapter**.




Step3.

- Click **“Yes”** to continue.



Step4.


- Select **“Yes, I want to restart my computer now.”** Item.
- Click **“Finish”** to complete and unplug the **“USB-IrDA Adapter”**.



➤ Under Windows 2000/XP


Step1.

- Move the cursor to “**My computer**” → “**Control Panel**” → “**Add/Remove Programs (for Windows 2000)**” “**Add or Remove Programs (for Windows XP)**” and double click.
- Select the “**USB-IrDA Adapter**” item and click “**Change/Remove**” button to uninstall the driver.



Step2.

- Click “**Yes**” to uninstall the **USB-IrDA Adapter**.



Step3.

- Click “**Finish**” to complete and unplug the **USB-IrDA Adapter**.

