

LINDY®

CONNECTION PERFECTION

Motorised Plasma/LCD Trolley

User Manual

English



LINDY No. 40729

www.lindy.com



User Manual

Introduction


Thank you for purchasing the LINDY Motorised LCD/Plasma Trolley. This sturdy trolley allows you to mount your Plasma or LCD on to a mobile stand for easy transportation with the added benefit of adjusting the height via remote control for easier viewing. It's an ideal product for schools, colleges and businesses with shared video resources which need to be easily moved between rooms. It consists of two heavy gauge steel uprights and includes a fitted shelf to store a VCR or DVD player. The design allows the TV to be tilted downwards 15° and can turn left or right for up to 20°.

Specifications


- The motorised height adjustment can easily position the TV from 1000mm to 1450mm high from the ground using the included remote control
- Universal fit, suitable for most plasma and LCD displays from 37" to 60"
- Adjustable design allows the screen to be tilted up to 15° and rotated up to 20°
- Includes locking wheels for portability and safety
- Includes a reinforced fixed glass shelf
- Heavy gauge steel construction with powder coated finish
- Supports displays weighing up to 50kg
- Meets Vesa standards: Min 200 x 200mm, Max: 800 x 450mm
- Assembly required

Assembly


A. Attach the four locking wheels to the base plate. Tighten with the supplied spanner.




B. Fasten the main centre unit (C) to the top of the base plate using the four (F) bolts.




- C. Remove the cover from the rear of the centre unit. Attach the remote control to the power supply & place the unit in the space. Replace the cover remembering to feed the trailing leads through the slot at the bottom of the cover.




- D. Next, attach the two bars (E) to the rear of your LCD or Plasma using bolts (J), washers (K) and spacers (L) if necessary.




- E. Attach the bracket support column (D) to the bars (E) on the rear of your LCD or Plasma using bolts (G) and washers (H), tightening with the supplied allen key (I).




- F. Hook the bracket support column (D) onto the centre unit (C) as shown. Secure the bottom with cap (M) and screws (N).




- G. The Plasma or LCD can be tilted up to 15° downwards and rotated up to 20° left or right.




- H. Feed the power and video cables to the LCD or Plasma through the cable tidy using trunking (O & P).



- I. Bolt the two brackets (T) to the front of the main centre unit using screws (W). Then insert bolts (V) in to the bottom of the brackets without fully tightening them.







- J. Finally insert the glass shelf (U) in to the brackets (T) and tighten the bolts (V). Be careful not to over tighten these bolts as you may damage the shelf.



User Manual

Product Dimensions



CE/FCC, Recycling Information

CE Certification

This equipment complies with the requirements relating to electromagnetic compatibility, EN55022/EN55024 class B for IEC/EN61000-2/3 the essential protection requirement of Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.



WEEE (Waste of Electrical and Electronic Equipment), Recycling of Electronic Products

United Kingdom

In 2006 the European Union introduced regulations (WEEE) for the collection and recycling of all waste electrical and electronic equipment. It is no longer allowable to simply throw away electrical and electronic equipment. Instead, these products must enter the recycling process.

Each individual EU member state has implemented the WEEE regulations into national law in slightly different ways. Please follow your national law when you want to dispose of any electrical or electronic products. More details can be obtained from your national WEEE recycling agency.

Germany

Die Europäische Union hat mit der WEEE Richtlinie umfassende Regelungen für die Verschrottung und das Recycling von Elektro- und Elektronikprodukten geschaffen. Diese wurden von der Bundesregierung im Elektro- und Elektronikgerätegesetz – ElektroG in deutsches Recht umgesetzt. Dieses Gesetz verbietet vom 24.März 2006 an das Entsorgen von entsprechenden, auch alten, Elektro- und Elektronikgeräten über die Hausmülltonne! Diese Geräte müssen den lokalen Sammelsystemen bzw. örtlichen Sammelstellen zugeführt werden! Dort werden sie kostenlos entgegen genommen. Die Kosten für den weiteren Recyclingprozess übernimmt die Gesamtheit der Gerätehersteller.

France

En 2006, l'union Européenne a introduit la nouvelle réglementation (DEEE) pour le recyclage de tout équipement électrique et électronique.

Chaque Etat membre de l' Union Européenne a mis en application la nouvelle réglementation DEEE de manières légèrement différentes. Veuillez suivre le décret d'application correspondant à l'élimination des déchets électriques ou électroniques de votre pays.

Italy

Nel 2006 l'unione europea ha introdotto regolamentazioni (WEEE) per la raccolta e il riciclo di apparecchi elettrici ed elettronici. Non è più consentito semplicemente gettare queste apparecchiature, devono essere riciclate. Ogni stato membro dell' EU ha tramutato le direttive WEEE in leggi statali in varie misure. Fare riferimento alle leggi del proprio Stato quando si dispone di un apparecchio elettrico o elettronico.

Per ulteriori dettagli fare riferimento alla direttiva WEEE sul riciclaggio del proprio Stato.

LINDY No. 40729



1st Edition August 2010
www.lindy.com