

LINDY®

CONNECTION PERFECTION

USB 5.1 Channel Audio Adapter - 42767

Quick Installation Guide

Windows XP, Vista & 7

1. Switch your computer on and connect the USB 5.1 Audio Adapter to a vacant USB port
2. Windows will detect and install the adapter automatically
3. Once the installation has completed you insert the supplied CD in to your computer
4. Open the **Driver** folder and then the folder for your operating system
5. Double click on **setup.exe** to begin the installation process
6. When the installation has finished you will be prompted to restart your computer to complete the installation
7. When your computer has restarted complete the following steps to configure the USB Audio Adapter:

XP

8. Navigate to My Computer > Control Panel > Sounds and Audio Devices
9. Select the **Audio** tab and select **USB Audio Device** from the Sound playback default device dropdown box and then click **Apply**
10. Select the **Volume** tab and click the **Advanced** button in the Speaker settings box
11. Select the **Speakers** tab and then choose **5.1 surround sound speakers** from the **Speaker setup** drop down box and click **Apply**

Vista & 7

8. Navigate to Control Panel > Hardware and Sound > Manage audio devices
9. Select the **Playback** tab and then click on **Speakers – USB Sound Device** and then click **Configure**
10. Highlight **5.1 Surround** and then click **Next**
11. You will now be given the option to customise and test the speakers, once you have done this click **Next** and then **Finish**

Your USB Audio Adapter is now set up and ready to use, for further information on the features available from this product please refer to the User Manual on the supplied CD.

Mac OS X

1. Switch your computer on and connect the USB 5.1 Audio Adapter to a vacant USB port
2. Your computer will detect and install the adapter automatically
3. Select **Go** and then **Utilities** and click on **Audio Midi Setup**
4. Select the **Audio Devices** button and ensure that the **Default Input**, **Default Output** and **System Output** are all set to **USB Sound Device**
5. Next check that **Properties For:** is set to **USB Sound Device** and that the **Audio Output** is set to **6ch-16bit**
6. Now click **Configure Speakers** and then click **Multichannel**
7. You can now adjust the position of the 6 speakers to suit your preference, once you have done this click **Apply** to save your settings



For Home and Office Use
Tested to Comply with
FCC Standards